



REM.S/D.RA... TYPE ELECTRONIC REGULATORS SINGLE / DOUBLE SOLENOID PROPORTIONAL CONTROL VALVES




OVERALL DIMENSION AND MOUNTING BASES ON DIN GUIDES FOR REM.S.RA...



OVERALL DIMENSION AND MOUNTING BASES ON DIN GUIDES FOR REM.D.RA...



ARONDG SOFTWARE



AronDG program for the digital adjustment of the parameters of the REMS and REMD boards.

AronDG program for the digital adjustment of the parameters of the REMS and REMD boards.

The program is used to store (the settings are cancelled when the REM board is switched off) the following parameters:

- Minimum current
- Upward current ramp
- Upward current ramp
- Downward current ramp

Italian/English version: purchase order code **P35150003**.

NB: the AronDG software can be used with all the REMS and REMD boards that have a TTL connector (production commencement year 2008).

SERIAL CABLE RS232/TTL



Ordering code **VE0110001**



REM connecting at computer with serial cable.